


These instructions
call for the use of non
LEGO® brand parts.




Parts List



Notes

Both varieties of train
wheels can be used.
Newer variety (2878c02)
requires substitute brass
rod axle cut to 40 mm.


These instructions
require two 1/8 in. (3.18
mm) diameter brass
tubes cut to 34 mm long.
Tubes should be de-
burred with a file after
cutting.




1





2





3





4





5




6





7




8




9




10



11



1



1x

1x

2




1x



12




2x



13




4x





14



2x



15



16

